nova®
Smart Tools, Powerful Solutions

SKU 5529173

Neptune Magnetic Emergency Stop Accessory

OPERATION MANUAL

For safety reasons please carefully read and understand these instructions

Parts List:

Part	SKU	Description	Qty
1	5529173	Emergency Stop	1

Specifications:

	Metric	Imperial
Overall Size	71mm (L) x 72mm (w) x 97mm(H)	2.8” (L) x 2.8” (w) x 3.8” (H)
Package Size	152mm(L) x 152mm (W) x 152mm (H)	6 (L) x 6” (W) x 56” (H)
Net Weight	07oz	.44lbs
Gross Weight	11oz	.69lbs

For all worldwide Inquiries, Repairs or Services (issues must be in writing)
Contact us at:
https://www.teknatool.com/support/

Assembly Instructions:

Tools Needed (Not Included): Phillips screwdriver		
1		
Unplug your machine and wait 5 minutes, then remove the three HMI screws.		
2		
Carefully tilt your HMI to the left. Becareful of the heat sensor cable attachted to the top green connector and the 5 pin HMI Cable. Remove the jumper as shown.		
3		
Remove the back nut of the cable gland and the cable port plug on the side of the HMI. Insert the cable gland into the hole and replace the gland nut on the inside of the HMI.		
4		
Connect the emergency stop cable into the 2 pin port where the jumper was. Give the cable a little slack then firmly tighten the front of the cable gland. Reattach the 3 HMI Screws.		

Teknatool Warranty

NOVA Limited Warranty

7229 Bryan Dairy Road Largo, FL 33777
teknatool.com | 727.954.3433

Our policy is one of continuous improvement. We, therefore, reserve the right to change specifications/designs without notice. This warranty is *Teknatool International Ltd* and *Teknatool USA Inc.* sole warranty, whether written or verbal, whether expressed or implied by law, trade, custom, or otherwise, whether of merchantability, fitness for purpose, or otherwise, except for remedies available to customers under the Consumer Guarantees Act or other legislation. For full warranty details and instructions on how to file a claim, please go to www.teknatool.com

nova®
Smart Tools, Powerful Solutions

SKU 5529173

Neptune Magnetic Emergency Stop Accessory

OPERATION MANUAL

For safety reasons please carefully read and understand these instructions

Parts List:

Part	SKU	Description	Qty
1	5529173	Emergency Stop	1

Specifications:

	Metric	Imperial
Overall Size	71mm (L) x 72mm (w) x 97mm(H)	2.8” (L) x 2.8” (w) x 3.8” (H)
Package Size	152mm(L) x 152mm (W) x 152mm (H)	6 (L) x 6” (W) x 56” (H)
Net Weight	07oz	.44lbs
Gross Weight	11oz	.69lbs

For all worldwide Inquiries, Repairs or Services (issues must be in writing)
Contact us at:
https://www.teknatool.com/support/

Assembly Instructions:

Tools Needed (Not Included): Phillips screwdriver		
1		
Unplug your machine and wait 5 minutes, then remove the three HMI screws.		
2		
Carefully tilt your HMI to the left. Becareful of the heat sensor cable attachted to the top green connector and the 5 pin HMI Cable. Remove the jumper as shown.		
3		
Remove the back nut of the cable gland and the cable port plug on the side of the HMI. Insert the cable gland into the hole and replace the gland nut on the inside of the HMI.		
4		
Connect the emergency stop cable into the 2 pin port where the jumper was. Give the cable a little slack then firmly tighten the front of the cable gland. Reattach the 3 HMI Screws.		

Teknatool Warranty

NOVA Limited Warranty

7229 Bryan Dairy Road Largo, FL 33777
teknatool.com | 727.954.3433

Our policy is one of continuous improvement. We, therefore, reserve the right to change specifications/designs without notice. This warranty is *Teknatool International Ltd* and *Teknatool USA Inc.* sole warranty, whether written or verbal, whether expressed or implied by law, trade, custom, or otherwise, whether of merchantability, fitness for purpose, or otherwise, except for remedies available to customers under the Consumer Guarantees Act or other legislation. For full warranty details and instructions on how to file a claim, please go to www.teknatool.com

nova®
Smart Tools, Powerful Solutions

SKU 5529173

Neptune Magnetic Emergency Stop Accessory

OPERATION MANUAL

For safety reasons please carefully read and understand these instructions

Parts List:

Part	SKU	Description	Qty
1	5529173	Emergency Stop	1

Specifications:

	Metric	Imperial
Overall Size	71mm (L) x 72mm (w) x 97mm(H)	2.8” (L) x 2.8” (w) x 3.8” (H)
Package Size	152mm(L) x 152mm (W) x 152mm (H)	6 (L) x 6” (W) x 56” (H)
Net Weight	07oz	.44lbs
Gross Weight	11oz	.69lbs

For all worldwide Inquiries, Repairs or Services (issues must be in writing)
Contact us at:
https://www.teknatool.com/support/

Assembly Instructions:

Tools Needed (Not Included): Phillips screwdriver		
1		
Unplug your machine and wait 5 minutes, then remove the three HMI screws.		
2		
Carefully tilt your HMI to the left. Becareful of the heat sensor cable attachted to the top green connector and the 5 pin HMI Cable. Remove the jumper as shown.		
3		
Remove the back nut of the cable gland and the cable port plug on the side of the HMI. Insert the cable gland into the hole and replace the gland nut on the inside of the HMI.		
4		
Connect the emergency stop cable into the 2 pin port where the jumper was. Give the cable a little slack then firmly tighten the front of the cable gland. Reattach the 3 HMI Screws.		

Teknatool Warranty

NOVA Limited Warranty

7229 Bryan Dairy Road Largo, FL 33777
teknatool.com | 727.954.3433

Our policy is one of continuous improvement. We, therefore, reserve the right to change specifications/designs without notice. This warranty is *Teknatool International Ltd* and *Teknatool USA Inc.* sole warranty, whether written or verbal, whether expressed or implied by law, trade, custom, or otherwise, whether of merchantability, fitness for purpose, or otherwise, except for remedies available to customers under the Consumer Guarantees Act or other legislation. For full warranty details and instructions on how to file a claim, please go to www.teknatool.com